TOP AND CONSOLE PARTS

29"GAS DRYER

For Models: 1CWGD5850SW0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: 1CWGD5850SW0
(White)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8562582	Instructions, Installation
	W10042950	Sheet, Cycle Feature
	8578183	Use & Care Guide
	8576803	Wiring Diagram
		Following May Be Purchased
		DO−IT−YOURSELF REPAIR MANUALS
	677818	Dryer
2	3401695	Wire, Jumper (Buzzer On/Off)
3	694419	Buzzer, Mini
4	8566035	Cap, End (L.H.)
5	717252	Plug, 2−Way Terminal
6	8274261	Panel, Rear Console
7	8530169	Switch, Temperature
8	8566032	Cap, End (R.H.)
9	693995	Screw, Hex Washer Head
10	8557857	Screen, Lint
11	8536939	Clip, Spring
12	8533971	Screw, 8−18 x 5/16
13	688983	Screw, 8−18 x 5/8
14	8312709	Clip−Console
15	3395683	Connector (Motor)
16	W10028870	Top
17	359625	Screw, 8−18 x 1/2
18	W10034380	Knob, Control (3)
19	3394427	Clip−Harness
20	8533951	Screw, Grounding
21	3406725	Timer Assembly (60 Hz.)
22	8558178	Control, Electronic
23	3391885	Connector, Edge
24	3397269	Connector−Timer
25	3401144	Connector, (PTS Relay)
26	3403499	Connector, 2−Position (Gas Valve)
27	3403498	Connector, 3−Position (Gas Valve)
28	3405152	Switch, End Of Cycle
29	3936144	Connector
30	8578863	Panel, Control
31	8299890	Harness, Wiring
32	W10034770	Knob, Push−To−Start
33	3347243	Connector 6−Circuit
34	3405154	Switch, Wrinkle Shield
35	3398094	Switch, Push−To−Start
36	W10034750	Timer Knob Assembly
37	94614	Terminal, Female
38	8566052	Bracket, Control

CABINET PARTS

For Models: 1CWGD5850SW0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: 1CWGD5850SW0
(White)

Illus. No.	Part No.	DESCRIPTION
1	697776	Screw, 10−32 x 5/8 (External Ground)
2	343641	Screw, 10−16 x 1/2
3	693995	Screw, Hex Head
4	8541400	Bracket, Cabinet
5	3396795	Cover, Block
6	3404162	Clamp, Motor (W/Shield)
7	3396805	Panel, Rear
8	344020	Power Cord
9	3980175	Clamp−Elbow
10	3406107	Door Switch Assembly
11	697773	Screw, 6−20 x 7/8
12	98669	Locator, Top
13	3357011	Screw, 10−16 x 1/2
14	W10041960	Spring, Door (2)
15	18849	Pad, Top Hinge
16	3392100	Foot, Dryer
	279810	Foot−Optional (Extended Length) (Package of 2) (Not Included.)
17	342043	Screw, 10−32 x 3/8
18	8530603	Cabinet (Includes Illus. 4)
19	98234	Clip, Ground (2)
20	18776	Lock, Front Top (2)
21	3395197	Panel Front
22	341029	Clamp, Pipe
23	685203	Clip, Felt Pad (2)
24	3389441	Catch, Door Assembly
25	3390731	Seal, Door
26	337189	Clip, Hinge (2)
27	694091	Screw, 8−18 x 3/8
28	8066056	Hinge, R.H.
	8066057	Hinge, L.H.
29	660658	Clamp, Motor
30	8066206	Motor Assembly 60 HZ.
31	8066184	Pulley, 60 HZ.
32	3400500	Bolt−5/16−18 x 3/4
33	696144	Strike, Panel
34	348780	Base, Motor
35	695737	Door, Rear
36	3393549	Door, Front
37	W10095180	Handle, Door
38	3406129	Seal & Bearing Assembly
39	3394975	Plug, Front Panel
40	3394083	Clip, Front Panel
41	8066217	Hinge, Top (2)
42	691366	Idler & Pulley Assembly
43	8066065	Belt, Drive
44	8318272	Burner Assembly, 60 Hz. (See Pages 7 & 8 For Further Burner Breakdown)

BULKHEAD PARTS

For Models: 1CWGD5850SW0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: 1CWGD5850SW0
(White)

Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	489463	Screw, 8−18 x 5/8
3	3388703	Washer−Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8−18 x 3/8
6	487909	Screw, 8−15 x 1/2
7	3392519	Fuse, Thermal
8	8066086	Drum Hole Plug
9	8318268	Thermostat, Internal−Bias
10	694089	Wheel, Blower
11	8577230	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10−16 x 1/2
14	8530285	Box, Heater
15	3403140	Thermostat, 205°F (96°C)
18	8066049	Funnel, Burner
19	3403634	Socket Assembly
20	3406124	Bulb
22	3977373	Bracket, Drum Light
23	3406022	Bracket, Bulkhead
24	3390647	Screw, 8−18 x 1/2
25	280010	Kit, Thermal Cut−Off (Includes Illus. 15)
26	3401707	Wire, Jumper
27	3976479	Pad, Sensor
28	690997	Ring, Tri
29	3399506	Shaft, L.H.
30	3399507	Shaft, R.H.
31	3397590	Roller, Support
32	348197	Washer, Support
33	3359452	Nut, 3/8−16
34	3403414	Bulkhead
35	338906	Sensor, Radiant
36	3402841	Lens, Drum Light
37	692526	Ring, Bearing
38	97787	Screw, 11−16 x 3/4
39	3406130	Seal, Rear Drum
40	695587	Drum Assembly
41	692490	Baffle, Drum (2)
42	3976434	Bracket, Support
43	90296	Clip
44	3403636	Baffle, Drum (1)
45	339956	Seal
46	696302	Shield, Exhaust

8318272 BURNER ASSEMBLY

For Models: 1CWGD5850SW0
(White)

USE WITH TYPE 1 − NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



8318272 BURNER ASSEMBLY

For Models: 1CWGD5850SW0
(White)

USE WITH TYPE 1 − NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	8318272	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8−32 x 5/8)
6	343641	Screw, 10−16 x 1/2
7	693986	Base, Burner
8	3387057	Screw, 8−18 x 3/8
9		Orifice, Burner
	234826	Type 1
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	8318277	Valve, 60 Hz. (Includes Pipe & Illus. #7)
11	694421	Screw, 8−32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
25	341029	Clamp, Pipe

Following Parts Not Illustrated

694572	Conversion Kit (Type 1) to Type (4) L.P.G.

BA−150

OPTIONAL PARTS (NOT INCLUDED)

For Models: 1CWGD5850SW0
(White)

Illus. No.	Part No.	DESCRIPTION
		ACCESSORY PARTS
	279948	Kit, Dryer Repair
	346764	Kit, Hold−Down (Gas Dryer Mobile Home Installation)
	3406839	Dry Rack
	8522199	Kit, Dryer Vent Testing
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
	4392899	Biscuit
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350930	White
	4392901	Biscuit
	350938	Primer, Gray
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
	4392900	Biscuit (Uncut)